

SYSTEM 1 2 3
dining & lounge chair

Design by VERNER PANTON


1

The chair is mounting with a turnable function. If you wish to change the function of the chair to locked please follow this instruction. Otherwise the chair is ready to use.


Important!
To avoid damaging the substrate, we recommend that the attached filter knobs to be placed on the bottom, before the chair is used.

Notice!
The System 1 2 3 chair is for indoor use only!


2




3



4



5



6

Maintenance of System 1 2 3:

Footplate: wipe off with a damp cloth. – Grease stains can be removed with soapy water.

Fabric: Regular cleaning is important in order to keep the upholstery looking its best and to prolong its life. Dust and dirt wear the textile and also reduce its fire-retardant properties.

Vacuum frequently on medium power, ideally every week. Remove non-greasy stains by carefully dabbing with a lint-free cloth or sponge wrung out in clean warm water. Afterwards, if necessary, clean by dabbing with soapy water or water with a little washing-up liquid added. See formulae. Finally, dab the surface with clean, tepid water.

DESIGNED
IN THE PAST
MADE FOR
TOMORROW

VERPAN ApS
Egeskovvej 29
8700 Horsens
Denmark

www.verpan.com

info@verpan.dk