


ASSEMBLY INSTRUCTIONS


COUCHTISCH



Parts



Top x 1



Legs x 3




Allen key x 1




Screws X9
M6 x 20

STEP 1



STEP 2



FINAL PRODUCT

