

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓙ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio





Ⓙ Instrukcja montażu

Ⓙ Navod na montaž

Ⓙ Instrucțiuni de montaj

Ⓙ Инструкция по монтажу

36-1027-76-000





Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov
Név • Denumire • Isim • Название






Nr. Nr. • No. • N° • Č • Sz • Номер

Typ • Тип • Type • Tip • Tipus • Druh • Тіро • Тип




Detail specification

A.i. Nr.	Article Nr.	pcs
H2	112510-76	x1
G3	112222-26	x2
G	112221-26	x2
E	112111-26	x2
F	112112-26	x2




Fitting specification


A.i. Nr.	Article Nr.	Dimentions	pcs
1	1-000013-00	8x40	x8
2	1-000172-07	7x70	x8
3	1-000015-07	z=4	x1
4	1-000168-07	4.5x80	x4



1



2



3



4

1-000001=

