

Broil King®



Broil King Imperial™





XL
9577-82
9577-83
9577-86
9977-82
9977-83
9977-86



Broil King Imperial™

XLS
9578-82
9578-83
9578-86
9978-82
9978-83
9978-86




HARDWARE INCLUDED / MATERIAL INCLUS / EQUIPOS INCLUIDO


Y-12865		X32	Y-11793		X8
Y-29306		X4			

TOOLS REQUIRED / OUTILS NECESSAIRES / HERRAMIENTAS NECESARIAS




1







3	(24) 
---	--








3	 (24)
---	--








4




5







6








7

(1) 













11



(2)



12





13


(1)



AA







PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9577-82	9577-83	9577-86	9578-82	9578-83	9578-86
1	27008-703	FIRE BOX ASSEMBLY	1	1	1	1	1	1
1A	27003-703	FIRE BOX ASSEMBLY	1	1	1	1	1	1
2	86005-301	LID ASSEMBLY	1	1	1	•	•	•
	86005-303	LID ASSEMBLY	•	•	•	1	1	1
2A	86003-301	LID ASSEMBLY	1	1	1	•	•	•
	86003-303	LID ASSEMBLY	•	•	•	1	1	1
5	27249-904	GREASE SHIELD	6	6	6	6	6	6
7	Y-11544S	BURNER SCREW	6	6	6	6	6	6
8	S21242	BURNER MOUNT CLIP	6	6	6	6	6	6
18	22005-283	CAST STAINLESS STEEL GRID	4	4	4	4	4	4
18A	22005-283	CAST STAINLESS STEEL GRID	2	2	2	2	2	2
20	22005-991	GRID - WARMING RACK	1	1	1	1	1	1
20A	22003-991	GRID - WARMING RACK	1	1	1	1	1	1
22	22225-014A	COLLECTOR BOX ASSEMBLY	1	1	1	1	1	1
22A	22223-014A	COLLECTOR BOX ASSEMBLY	1	1	1	1	1	1
25	22909-104D	BURNER	6	•	•	6	•	•
	22909-104E	BURNER	•	6	•	•	6	•
	22909-104NGE	BURNER	•	•	6	•	•	6
26	22001-769	CONTROL KNOB	6	6	6	6	6	6
26A	22001-669	CONTROL KNOB	2	2	2	2	2	2
27	22002-264	CONTROL BEZEL	6	6	6	6	6	6
27A	22001-164	CONTROL BEZEL	2	2	2	2	2	2
28	27028-493	CONTROL COVER	1	1	1	1	1	1
32	10111-15A	HOSE ASSEMBLY	1	1	1	1	1	1
34	S13473-073	HOSE-SIDE BURNER	1	•	•	1	•	•
	S13473-079	HOSE-SIDE BURNER	•	1	•	•	1	•
	S13473-109	HOSE-SIDE BURNER	•	•	1	•	•	1
34A	Y-11230	HITCH CLIP - SIDE BURNER	1	1	1	1	1	1
35	29018-072	CONTROL ASSEMBLY	1	•	•	1	•	•
	29018-075	CONTROL ASSEMBLY	•	1	•	•	1	•
	29018-076	CONTROL ASSEMBLY	•	•	1	•	•	1
36	10342-T18	ELECTRODE – SIDE BURNER	1	1	1	1	1	1
37	20809-957	TUBE-REAR BURNER ASSY	1	1	1	1	1	1
38	Y-11990	HEX NUT	1	1	1	1	1	1
43	10342-E13	ELECTRODE	2	2	2	2	2	2
43A	10342-E22	ELECTRODE	1	1	1	1	1	1
44	10342-45	ELECTRONIC IGNITOR	1	1	1	1	1	1
44A	25070-92	IGNITOR HARNESS	1	1	1	1	1	1
44B	25070-93	IGNITOR BUTTON	1	1	1	1	1	1
47	21035-991	GREASE RAILS	2	2	2	2	2	2
47A	21033-991	GREASE RAILS	2	2	2	2	2	2
48	22009-901	GREASE PAN	2	2	2	2	2	2
49	27055-901	GREASE TRAY	1	1	1	1	1	1
49A	27053-901	GREASE TRAY	1	1	1	1	1	1
51	22209-903	FLAV-R-WAVE®	6	6	6	6	6	6
56	24005-239	HANDLE	1	1	1	1	1	1
56A	24003-239	HANDLE	1	1	1	1	1	1
58	26009-917	HANDLE END CAP	4	4	4	4	4	4

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9577-82	9577-83	9577-86	9578-82	9578-83	9578-86
58A	24009-938	HANDLE WEDGE	4	4	4	4	4	4
59	10081-BK630	NAMEPLATE	2	2	2	2	2	2
60	10571-6	HEAT INDICATOR	2	2	2	2	2	2
65	20005-000	MATCH LIGHT - STICK	2	2	2	2	2	2
68	23275-111A	RIGHT DOOR	1	1	1	•	•	•
	23275-113A	RIGHT DOOR	•	•	•	1	1	1
69	23275-131A	LEFT DOOR	1	1	1	•	•	•
	23275-133A	LEFT DOOR	•	•	•	1	1	1
70	21079-906	HANDLE END CAP	8	8	8	8	8	8
71	21171-23	HANDLE - SMALL	4	4	4	4	4	4
74	Y-99100	DRAWER SLIDE	4	4	4	4	4	4
77	21165-111A	DRAWER ASSEMBLY	2	2	2	•	•	•
	21165-113A	DRAWER ASSEMBLY	•	•	•	2	2	2
78	21335-111	BRACKET - DOOR CATCH	1	1	1	1	1	1
78A	21333-921	BRACKET - DOOR CATCH	1	1	1	1	1	1
80	21109-905R	SIDE PANEL	3	3	3	3	3	3
82	25208-201R	SHELF - CABINET	1	1	1	1	1	1
83	21065-901R	DRAWER CENTER MOUNT	1	1	1	1	1	1
84	21069-901	DRAWER SUPPORT	1	1	1	1	1	1
88	21305-925R	PANEL - REAR	1	1	1	1	1	1
88A	25308-925R	PANEL - REAR	1	1	1	1	1	1
90	25098-935	BASE	1	1	•	1	1	•
	95098-955	BASE	•	•	1	•	•	1
100	21039-911	BRACKET - CASTOR SUPPORT	3	3	3	3	3	3
101	21039-301	LOWER TANK SUPPORT	1	1	•	1	1	•
102	10892-23	CASTOR	3	3	3	3	3	3
102A	10892-285	CASTOR	3	3	3	3	3	3
114	23102-613	SHELF	1	1	1	1	1	1
115	23102-653	SHELF-SIDE BURNER	1	1	1	1	1	1
123	Y-12117	SIDE BURNER LID STOP	2	2	2	2	2	2
124	23000-271	SIDE BURNER BODY	1	1	1	1	1	1
125	23000-253	COVER-SIDE BURNER	1	1	1	1	1	1
126	10390-R81D	SIDE BURNER	1	•	1	1	•	1
	10390-R81A	SIDE BURNER	•	1	•	•	1	•
128	23009-99	GRID	1	1	1	1	1	1
130	27905-354	BURNER ROTISSERIE	1	1	1	1	1	1
131	10693-095	REAR BURNER-ORIFICE	1	•	•	1	•	•
	10693-099	REAR BURNER-ORIFICE	•	1	•	•	1	•
	10693-109	REAR BURNER-ORIFICE	•	•	1	•	•	1
133	S15271	HANDLE	1	1	1	1	1	1
134	S15270	BALANCER	1	1	1	1	1	1
135	S15299	WASHER	1	1	1	1	1	1
136	S15263	BUSHING	2	2	2	2	2	2
137	S15260	SPIT ROD	1	1	1	1	1	1
138	S15287	4 PRONG FORKS	2	2	2	2	2	2
139	57039-901	ROTISSERIE BRACKET	1	1	1	1	1	1
140	S21125	SCREW #8 X 1/2	6	6	6	6	6	6
141	Y-11559	SCREW 1/4-20X 3/4	12	12	12	12	12	12

PARTS LIST / LISTE DES PIECES

KEY #	ITEM #	DESCRIPTION	9577-82	9577-83	9577-86	9578-82	9578-83	9578-86
144	Y-12220	BUSHING	1	1	2	1	1	2
145	S21235	HINGE PIN	2	2	2	2	2	2
145A	10240-17	HINGE PIN	1	1	1	1	1	1
146	S21233	HITCH PIN CLIP	3	3	3	3	3	3
147	Y-11231	LID BUMPER	4	4	4	4	4	4
148	10240-20	DOOR PIN	2	2	2	2	2	2
149	Y-11551	DOOR PIN	2	2	2	2	2	2
150	Y-12124	DOOR PIN CAP	2	2	2	2	2	2
151	Y-11567	SCREW M8 SHOULDER	8	8	8	8	8	8
152	Y-12222	MAGNET	2	2	2	2	2	2
153	Y-12223	SNAP IN MAGNET	2	2	2	2	2	2
154	Y-11560	SCREW 1/4-20 X 1-1/2	12	12	12	12	12	12
155	S21124	SCREW #8 X 1/2	32	32	32	32	32	32
156	Y-11793	NUT 1/4-20	14	14	10	14	14	10
157	Y-12835	SCREW #6-32 X 1/4	2	2	2	2	2	2
158	Y-12646	SHOULDER SCREW #8-32	2	2	2	2	2	2
159	S21136	SCREW #8-32 X 3/8	22	22	22	22	22	22
160	Y-29304	SCREW #10-24 X 3/8	2	2	2	2	2	2
161	Y-29310	SCREW #10-24	4	4	4	4	4	4
162	S35095	SCREW #10-24 X 3/4	2	2	2	2	2	2
163	S35094	SCREW #10-24 X 5/8	2	2	2	2	2	2
164	S21084	SCREW #14 X 5/8	8	8	8	8	8	8
169	S21061	WING NUT	2	2	2	2	2	2
170	Y-12084	NUT - 10-24	6	6	6	6	6	6
171	S15246	ROTISSERIE MOTOR	1	1	1	1	1	1
172	S15508	REAR BURNER ELECTRODE	1	1	1	1	1	1
173	S21362	SPRING	1	1	1	1	1	1
174	Y-12871	SCREW M4 X 0.7	2	2	2	2	2	2
181	25070-91	WIRE - OVEN LIGHT	1	1	1	1	1	1
181A	25070-95	LIGHT SWITCH	1	1	1	1	1	1
182	25020-71	OVEN LIGHT	3	3	3	3	3	3
183	20589-CH	TRANSFORMER PLUG	•	1	1	•	1	1
	20589-EU	TRANSFORMER PLUG	1	1	1	1	1	1
	20589-UK	TRANSFORMER PLUG	•	1	1	•	1	1
184	20589-90U	TRANSFORMER	1	1	1	1	1	1
185	25030-72	WIRE - OVEN LIGHT	1	1	1	1	1	1
186	Y-12865	SCREW 1/4-20 X 1/2	47	47	43	47	47	43
187	25030-70	WIRE - OVEN LIGHT	1	1	1	1	1	1
190	25020-84	WIRE - LED LIGHTS	1	1	1	1	1	1
191	25020-84	WIRE - LED LIGHTS	1	1	1	1	1	1
192	Y-29306	SCREW #10-24 X 3/4	4	4	4	4	4	4
193	SP11-25	LID BUMPER	4	4	4	4	4	4

